

Effective Date:

January, 1980

1. Inspect belts and set screws on fan, motor, couplings and gear reducer.
2. Clean and inspect distribution basin. Suction screen drift eliminators as required.
3. Tighten loose bolts.
4. Check for algae buildup, treat for same.
5. Check for hog or noisy motor bearings.
6. Check for excess noise and vibration.
7. Verify fill valve operation.
8. Check for leaks.

3. Check oil level in gear reducer.

Semiannual:

2. Lubricate motor bearings.

Annual:

1. Check for water in gear reducer, change oil.
2. Change oil in gear case.

3. Change grease in motor.

4. Drain tower in the fall.